

# **PRODUCT DATASHEET**

# OUTDOOR LIGHTING | OUTDOOR- UNDERWATER

Outdoor lighting | Recessed mounted linear underwater light |6w|Square shape Code# OTUW17007-6



### **Areas of Application**

- Swimming pool
- Fountains
- Aquariums
- Waterscape sculpture
- Waterfalls
- Rivers

#### **Product Features**

- IP68 waterproof
- High luminous efficacy, high CRI
- Uniform light output and good consistency, without flicker
- Anti-oxidation, anti-corrosion
- CCT optional and dimmable
- Easy and quick installation
- Good heat dissipation

## **Complete Product Data**

Code#	OTUW17007-6	
Wattage	6w	
Installation Type	Recessed	
Dimension	195mm*80mm*60mm	
Cutout	181mm*58mm*90mm	
IP Rating	IP68	
IK Rate	IK08	
Luminous Flux	/	
Beam Angle	8°, 12°, 25°, 40°, 60°	
Working Temperature	-25℃ ~55℃	
Certificates	/	
Warranty	3 Years	
Packing Size	/	

### **Driver Data**

Driver Brand	Tridonic, Osram, Philips, Lifud, Euchips, Eaglerise, etc.
Input Voltage	DC24V
Output Voltage	/
Output Current	/
Power Factor	>0.5 as standard; >0.9 optional
Efficiently	87% @230v
IP Rating	IP20
Dimmable	Non-Dimmable/Triac/0-10v/Dali Optional
Free Flicker	Yes
Certificates	CE, CB, CCC, ENEC
Warranty	3/5 Years


## Material&Housing Data

Housing Color	Silver
Reflector Color	/
Housing Material	316 stainless stee + tempered glass


### **Photometric Data**

Cree/ Osram /Bridgelux/ Epistar etc.
SMD
2700К, 3000К, 4000К, 6000К
>80
>50000Hrs
100-120lm/w

#### **Dimensions&Installation**







**PLEASE FIND A QUALIFIED ELECTRICIAN FOR INSTALLATION**. Please read the instructions before you install and use the underwater light.

- 1. Make sure the power is turned off in which you are installing the products.
- 2. Install the pre-buried bucket underground, the top surface should be at the same level as the ground, and the cable needs to pass through the pre-buried bucket. (Fig 1)
- 3. Connect the cables to the lights. Keep it long enough for future maintenance. (Fig 2)
- 4. Put the light fixture into the pre-buried bucket. (Fig 3)
- 5. Restore power at the source and the installation is complete.